

SNACK

Product Manual

Installation, use and maintenance



INDEX

1. INTRODUCTION	4
2. TECHNICAL CHARACTERISTICS	5
2.1. Main characteristics Mychef Snack	5
3. GENERAL SAFETY AND ACCIDENT PREVENTION REGULATIONS	6
3.1. Personnel responsible for using the equipment	6
3.2. Electrical hazard	6
3.3. Thermal hazard	6
3.4. Corrosion hazard	7
4. RECEPTION, TRANSPORT AND POSITIONING	8
4.1. Reception	8
4.2. Transport	8
4.3. Positioning	9
5. INSTALLATION	11
5.1. Electrical connection	11
5.1.1. Three-phase connection 400V 3L+N	12
5.1.2. Three-phase connection 230V 3L	12
5.1.3. Single-phase connection 230V L+N	12
5.2. Water connection	13
5.2.1. Water input	13
5.2.2. Water connection kit to carafe	14
5.3. Vapour condensation hood	14
6. USE	15
6.1. Control Panel	15
6.1.1. Switching on the equipment	20
6.1.2. Cooking control	20
6.1.3. Start of the cooking cycle	23
6.1.4. End of cycle	24
6.1.5. Speed selection	24
6.1.6. Saving a program	25
6.1.7. Retrieve a program	25
6.1.8. Quick memories	26
6.2. NightWatch	26
6.3. Errors and alarms	27

7. REMOTE CONTROL USE.....	29
7.1. Remote control setup	29
7.1.1. Creating a new user	29
7.1.2. Wi-Fi connectivity	30
7.1.3. Linking the oven to the device (mobile phone, tablet or computer)	32
7.1.4. Control panel.....	33
7.2. Google home setup and voice assistant	36
7.2.1. Synchronizing oven to Google Home.....	36
7.2.2. Voice commands for oven control	40
7.2.3. Adding automated routines.....	41
7.3. Support functions.....	44
7.3.1. Reset Wi-Fi settings.....	44
7.3.2. Show MAC address.....	44
7.3.3. Unlink the "Mychef Control" service	45
7.3.4. Desktop application for intelligent control	45
7.4. Table of states	46
7.5. Recipes	46
8. MAINTENANCE	48
8.1. Cleaning.....	48
8.1.1. Suction.....	48
8.1.2. Door gasket	49
8.1.3. Outer housing.....	50
8.1.4. Control panel.....	50
8.1.5. Front water drain.....	50
8.1.6. Interior/exterior door compartment	50
8.2. Preventive maintenance.....	51

1. INTRODUCTION

This manual has been carefully prepared and reviewed to provide reliable information and assistance for proper installation, use, and maintenance that will ensure proper operation and prolong the life of the oven. This manual is divided into three parts, the first part dedicated to the installation of the equipment at the working point, and the second part focused on the use and the third part in the cleaning and maintenance of the oven.



Before any intervention or use of the equipment, it is necessary to read this manual carefully and completely.

The manufacturer declines all implicit or explicit responsibility for any errors or omissions it may contain.

- The oven may not be used by personnel who have not received any kind of training, and who do not have the necessary skills or experience for the proper functioning of the equipment. Do not let children use or play with the equipment.
- The owner of the equipment is obliged to have this manual read by personnel responsible for its use and maintenance and to keep this manual in a safe place for use by all users of the equipment and for future reference. If the equipment is sold to others, they must be given this manual.
- This oven must only be used for its intended purpose, i.e., cooking, heating, regenerating or dehydrating food. Any other use can be dangerous and can result in personal injury and property damage.
- The equipment is shipped from the factory once it has been calibrated and has passed rigorous quality and safety tests that ensure its correct operation.



The manufacturer will disclaim any responsibility for problems caused by improper installation, modification, use or maintenance.

2. TECHNICAL CHARACTERISTICS

2.1. Main characteristics Mychef Snack

	SNACK 4 GN 2/3	SNACK 4 GN 1/1
Exterior dimensions (Width x Depth x Height) (mm)	620x690x522	760x760x522
Capacity	4 GN 2/3	4 GN 1/1

Table 1. Main characteristics of Mychef Snack ovens

The maximum recommended food load per GN 1/1 tray is 5 Kg. The maximum recommended food load per GN 2/3 tray is 3.5 Kg.

3. GENERAL SAFETY AND ACCIDENT PREVENTION REGULATIONS

3.1. Personnel responsible for using the equipment

The use of the equipment is reserved for trained personnel.



Personnel who perform any action on the oven, such as operation, cleaning, installation, handling, etc., must be familiar with the safety regulations and the Operating Instructions.



Do not allow unauthorized personnel to use, handle or clean the equipment.

3.2. Electrical hazard

Work on the electrical supply side and access to live parts may only be carried out by qualified personnel under their own responsibility. In any case, such access must be made with the equipment disconnected from the power supply.

If the appliance is placed on a cart or on tables that have some mobility, do not allow it to move while connected to the power supply to avoid possible damage to wiring, drainage pipes or water inlets. If the equipment is to be moved or repositioned, the cables and the drainage and water intake pipes must be disconnected.

3.3. Thermal hazard

When the equipment is in operation, the door should be opened slowly and carefully to avoid possible burns from steam or hot air that may escape from inside the cooking chamber.



Keep the ventilation openings free of obstacles. Do not install the equipment in the vicinity of flammable products. Avoid positioning the oven near heat sources such as stoves, grills, fryers, etc. Check the safety distances in chapter Positioning.



DANGER OF ACCIDENT! Be careful when using food containers in the oven when the top tray is 160 cm or more high. There is a risk of injury caused by the hot contents of the trays.



While the oven is in operation, avoid touching metal parts and the door glass as they may exceed 60°C. Touch only the handle and the control panel.

3.4. Corrosion hazard

When using cleaning products, special attention and appropriate safety measures should be taken when handling these products. Always read the safety data sheet for the different chemicals before use and follow the instructions for use. These products in contact with any part of the body are abrasive and can cause skin and eye irritations and causticity.

During cleaning of the oven and in the event of aerosols or mist forming when handling cleaning products, wear a mask with a P2 / P3 type particle filter, goggles for protection against splashes and/or splashes and chemical protection gloves.

DA21 cleaning products have been specially formulated for the correct cleaning and protection of Mychef ovens with automatic washing. The product contains, in addition to detergent, polish for a perfect finish. The use of this detergent is mandatory in the Mychef Snack ovens.



Use DA21 detergent in the Mychef Snack. The use of other products will void the warranty.

4. RECEPTION, TRANSPORT AND POSITIONING

Before carrying out the installation, the dimensions of the site where the equipment is to be placed and the electrical and water connections must be verified and seen to be within the parameters detailed in section 4.3.

4.1. Reception

Once the oven has been received, check that the model purchased corresponds to the order.

Check that the packaging has not been damaged during transport and that no parts of the equipment are missing. If you detect any anomaly or problem, contact your dealer immediately.

4.2. Transport

The equipment should be transported in its original packaging to the closest location to the point of installation to avoid damage as much as possible. It is recommended to keep the original packaging until the equipment is properly installed and in operation.

To move the equipment and place it in your workspace, the following observations should be taken into account:

- The measurements of the different models to pass through narrow places (corridors, doors, narrow spaces). See chapter 2.
- The handling must be done with the necessary personnel to move the load of the furniture taking into account the current occupational safety regulations at the place of installation.
- The oven must always be in an upright position during transport. It must be lifted perpendicularly to the ground and transported parallel to it.
- Make sure that during transport it does not tip over and is not hit by any object.



Be careful with the legs and the siphon when positioning the oven on the final location.

4.3. Positioning

- Place the oven at a comfortable distance from the wall so that the electrical and water connections can be made. There must be a minimum clearance from the oven parts to allow for proper ventilation and cooling. This minimum distance is:
 - o 50mm on the left and right sides
 - o 50mm from the rear
 - o 500mm from the top
- The equipment should be placed on a Mychef support table or wall mount.
- If there are sources of heat or steam near the equipment (stove, grill, iron, deep fryer, pasta cooker, kettle, tilting frying pan etc.), these must be at a distance of more than 1 metre.
- Check that the oven is not exposed to hot air or vapours in the areas where the cooling fans are located (front right and rear left).




Figure 1. Suction areas for cooling

- Once it is placed in the workspace, check that it is level.




Figure 2. Example of a suitable location for installation



Be extremely careful with the cooling areas of the oven. If it sucks in vapours or hot air it can drastically reduce the life span of the components.



For the installation of Mychef stacked ovens, follow the instructions supplied with the corresponding stacking kit.

5. INSTALLATION

5.1. Electrical connection

Check that the voltage reaching the point where the oven is to be switched on corresponds to the operating voltage of the equipment.

The following table indicates the electrical characteristics of each oven:

	Voltage	Power (kW)	Rated current (A)	Cross-section cable (mm ²)
4 GN 1/1	400/3L+N/50-60	6.3	10	1.5
	230/3L/50-60	6.3	17	2.5
	230/L+N/50-60	6.3	27	4.0
4 GN 2/3	230/L+N/50-60	3.6	16	1.5

Table 2. Electrical connection characteristics

Before carrying out any electrical work, make sure that no electrical current is supplied at the point of connection of the equipment.

The device must be connected to the mains via an all-pole switch with a contact opening distance of more than 3mm. Also install a class A differential device and an overcurrent protection.

Always ensure effective grounding.

Connect the equipment to an equipotential bonding system  using the contact specially provided for this purpose (see equipotential bonding sign on the bottom left of the equipment). If two pieces of equipment are stacked, both must be connected to the equipotentiality system.



The connection to an equipotential system guarantees additional safety in case of simultaneous earth leakage and differential failure.

The wiring and other safety devices used for the electrical installation must have the appropriate section for the equipment in question.



In any case, respect the regulations in force for the connection of the equipment to the low voltage network.

Before starting the electrical installation, check that the electrical requirements of the oven and the power supply are the same.

Once the connection has been made, check that no cables are loose and that they are all firmly attached. Also secure the cable gland.



Never connect a phase to neutral or ground. Check that the installation voltages correspond to those of the equipment.

The following subchapters show the three possible types of connections for Mychef ovens. The voltage of each oven can be found on its identification sticker.

5.1.1. Three-phase connection 400V 3L+N

Color		Cable
■	Brown	L1
■	Black	L2
■	Grey	L3
■	Blue	Neutral
■	Green-yellow	Grounding

Table 3. Three-phase cable 400V 3L+N

5.1.2. Three-phase connection 230V 3L

Color		Cable
■	Brown	L1
■	Black	L2
■	Grey	L3
■	Green-yellow	Grounding

Table 4. Three-phase cable 230V 3L

5.1.3. Single-phase connection 230V L+N

Color		Cable
■	Brown	L1
■	Blue	Neutral
■	Green-yellow	Grounding

Table 5. Single-phase connection 230V L+N

5.2. Water connection

5.2.1. Water input

Cold water (max. 30°C) ¾ inch 150 to 400 kPa dynamic flow pressure.

Drinking quality water with the following characteristics:

- Hardness between 3° and 6° FH
- PH between 6.5 and 8.5
- Chlorides (Cl-) less than 30 mg/L
- Chlorine (Cl2) less than 0.2 mg/L
- Iron (Fe) less than 0.1 mg/L
- Manganese (Mn) less than 0.05 mg/L
- Copper (Cu) less than 0.05 mg/L
- Conductivity less than 20uS/cm

Use of descaler and Mychef filter mandatory.



The use of water with different characteristics than those indicated may cause serious problems in the components of the oven, such as corrosion in the cooking chamber or the glass, premature failure of the solenoid valves, etc.



Periodically check the quality of the water in the oven.

The oven has a water inlet ¾" at the back of the oven for steam generation and for self-cleaning processes.




Figure 3. Water intake



In the case of a new installation, the water must be left to run until the connection is completely purified. This operation must be repeated each time work or repairs are carried out on the water system that feeds the oven.

5.2.2. Water connection kit to carafe

Refer to the installation manual supplied with the water pump kit for installation.



The water pump kit is an optional extra. The pump can be installed once the oven is installed.

5.3. Vapour condensation hood

Refer to the installation manual supplied with the fume hood for installation.



The vapour condensation hood is an optional extra. The hood can be installed once the oven is installed.

6. USE

6.1. Control Panel

The control panel of the Snack ovens has three cooking phases, it allows managing the humidity, temperature, time and fan speed parameters, and saving programs. In addition, it has eight quick access programs.

The figure below shows the control panel for the Mychef Snack ovens. It consists of a central screen with displays, indicators, and buttons.



Figure 4. Control panel

The functionality of each of them is explained below:



Figure 5. Control panel detail

Block	Function	Description
A	Phase 1 button	Button for selecting the first cooking phase.
B	Phase 1 indicator	Flashing, it indicates we are in phase 1. In fixed color, it indicates that this phase is active.
C	Phase 2 button	Button for selecting the second cooking phase.
D	Phase 2 indicator	Flashing indicates we are in phase 2. In fixed color, it indicates that this phase is active.
E	Phase 3 button	Button for selecting the third cooking phase.
F	Phase indicator 3	Flashing indicates we are in phase 3. In fixed color, it indicates that this phase is active.
G	Display screen	Displays the selected parameter: humidity, temperature, time, or fan speed.
H	Program button	Allows to save or retrieve a program.
I	Adjustment button -	Decreases the selected parameter: program, level, humidity, temperature, time, or fan speed.
J	Adjustment button +	Increases the selected parameter: program, level, humidity, temperature, time, or fan speed.
K	Level button	Allows to adjust the parameters of a fermenter from the same control.
L	Moisture button	Moisture selection button.
M	Temperature button	Temperature selection button.
N	Time button	Time selection button
O	Fan speed button	Fan speed selection button
P	Quick memory button block M1..M8	With a long press, it records the current parameters in a specific memory. With a short press, it executes the cooking in memory.
Q	START/STOP button	Oven on/off and start/stop button. If the oven is on but not baking, slight pressure will start the preheating. If the oven is preheating, slight pressure will skip the preheating. If the oven is on and baking, slight pressure will cancel the baking cycle.


Table 6. Control panel description

The central display is a very important part when interacting with the oven, since it indicates the value of each cooking parameter.



Figure 6. Central screen

The parameter display format is explained below:

Icon	Function
	<p>The moisture level is shown with an H in the first digit. The humidity value is shown next.</p>
	<p>The chamber temperature is shown with a T in the first digit. The temperature value in degrees Celsius is shown next.</p>
	<p>The cooking time is shown with the two central points. The two digits on the left are the hours, and the two digits on the right are the minutes.</p>
	<p>Cooking can also be continuous. In this case, CONT appears on the display. For continuous cooking, press the adjustment key - until CONT appears in the display.</p>
	<p>The fan speed is shown with an F in the first digit. If the convection fan is on high speed, HI is displayed. Otherwise, if the convection fan is at a low speed, LO appears.</p>

	<p>The program is shown with a P in the first digit, followed by the program number.</p>
	<p>The level is shown with "THIS" or "FER".</p>
	<p>Level 1 (THIS) accesses the oven parameters, and level 2 (FER) accesses the proofer parameters (OPTIONAL).</p>
	<p>This icon indicates that a cooking process has been completed.</p>
	<p>The DOOR message appears when the door is opened during a cooking process.</p>
	<p>The PREHEAT message is displayed during the oven preheating processes, alternatively with the current oven chamber temperature.</p>
	<p>The LOAD message indicates that the oven has reached preheat temperature and the oven is ready to charge. By closing the door, the cooking cycle will start.</p>
	<p>In the case of an error, the first two digits of the display show ER, followed by the error number. Refer to the chapter on errors for more information.</p>
	<p>It is possible to change the operating parameters of the oven. In the parameter edit menu, the central display shows a P, followed by the parameter number. The two digits on the right show the value of the parameter. Refer to the chapter on the configuration menu for more information.</p>

Table 7. Description of messages on the central screen

6.1.1. Switching on the equipment

The equipment is switched on or off by pressing the START/STOP button for two seconds.



In order to protect the oven from possible overheating, some protective elements may work even when the oven is switched off. When the oven is at a safe temperature it will automatically turn off.

If the equipment does not turn on, check the status of the safety thermostat and the service switch, located at the rear of the equipment.




Figure 7. Safety thermostat (A) and service switch (B)

6.1.2. Cooking control

6.1.2.1. Temperature and time-controlled cooking

In this mode the oven automatically brings the temperature in the chamber up to the value selected by the user so that when the door is opened and the food loaded, the temperature in the chamber will be the same as the one selected at the start of cooking. The oven automatically calculates the air temperature in the chamber and decides whether to heat it up to the value to be reached.

In the temperature and time control mode with temperature setting we choose a certain temperature and time by adjusting with the +/- buttons after having pressed the TEMPERATURE and TIME buttons respectively.

By pressing the START/STOP button, the oven will start to preheat the chamber and will stop when it has reached a level determined by the oven according to the temperature

requested by the user. At this point the display will show "Pht" alternately with the temperature of the chamber.




Figure 8. Preheating indicator

The preheating process can be skipped by slightly pressing the START/STOP key.

When it has reached the set temperature, the oven will warn the user with a buzzer and indicate "Load".



Figure 9. Load indicator

Once the oven is loaded and the door is closed, the cooking time will start to be deducted until it is finished. At this point, the time indicator will display the keyword "End", the oven will beep for one second and the interior light will light up until the user finishes cooking by pressing the START/STOP button slightly.

Example of cooking at 90° for 10 minutes:




Figure 10. Example. Cooking at 90°C for 10 minutes




Figure 11. Oven temperature

6.1.2.1. Cooking phases

At the top of the control panel there are three buttons, P1, P2, and P3, each corresponding to the cooking phases. Associated with each button is an indicator, which shows the status of the phase.




Figure 12. Buttons and cooking phase indicators

If the indicator for a particular phase is lit and blinking, it means that that phase is being displayed. If the indicator for a particular phase is lit continuously, it indicates that this phase is activated. If the indicator for a particular phase is off, it indicates that this phase is off. For example, in the figure below, phase P1 is on and displayed, phase P2 is on, and phase P3 is off:




Figure 13. Buttons and cooking phase indicators

To add a phase, with the oven not cooked, press the button with the inactive phase for two seconds.

To delete a phase, with the oven not cooked, press the button with the active phase for two seconds. Please note that it is not possible to delete the first cooking step P1.

To navigate between phases, press slightly on the number of the phase you want to display or edit.

6.1.3. Start of the cooking cycle

Once the cooking parameters have been selected, either in manual mode or in a certain program, the process can be started.

To do so, slightly press the START/STOP key to start preheating (see 6.1.2.1). If preheating is not necessary, the two central points will flash every second, indicating that the cooking process is underway. If a parameter other than time is selected on the display, the last point of this will flash to indicate that cooking is in progress.




Figure 14. Cooking indicator

If the door is opened during cooking, the timer stops, and the following message is shown in the central display:




Figure 15. Door open indicator

6.1.4. End of cycle

At the end of a cooking cycle, the unit signals this status visually and acoustically. Specifically:

- A beep is emitted.
- The light in the oven chamber turns on.
- The keyword END appears in the central display until the user finishes the cooking.

Press START/STOP to end the cooking process.

6.1.5. Speed selection

In any cooking mode the user can select the speed of the convection fan that best suits his needs. To do so, press the fan speed button. Then select the appropriate speed with the +/- buttons.




Figure 16. Maximum speed (HI) and reduced speed (LO)

6.1.6. Saving a program

To save a program, set the humidity, temperature, time, and speed of each of the phases you want. Then slightly press the PROG key and set the program number where you want to save the settings with the +/- keys. The figure below shows program 1.




Figure 17. Example, program 1

Once you have selected the program number where you want to save the settings, press the PROG button for two seconds to confirm the recording.

Note: Up to 40 programs can be saved (firmware 1.7 and higher).

6.1.7. Retrieve a program

To recall a program, press the PROG key slightly and set the program number where you want to save the settings with the +/- keys. The figure below shows program 1.




Figure 18. Example, program 1

Then slightly press the PROG key to display the program settings. You can also slightly press the START/STOP key to start the program directly.

6.1.8. Quick memories

The oven has 8 quick access memories, independent of the programs, numbered from M1 to M8.

To save a quick memory, set the humidity, temperature, time, and speed of each of the phases you want. Then press the button in the memory where you want to save the settings for two seconds.

To start a cooking process stored in quick memory, slightly press the key of the memory you want to execute.

In firmware versions 1.7 and higher, the quick memories correspond to the programs. That is, P1 stores the same cooking parameters as M1, etc. In previous versions, the memories are independent of the programs.

6.2. NightWatch

NightWatch allows the oven to automatically continue a cooking process after a power failure. This functionality is especially useful for unattended cooking.



This function will only continue with one cooking in the event of a power failure and subsequent recovery of the power supply.



This function can be disabled by your dealer. Make sure that you fully understand the risks of its use.

When a power failure and subsequent restoration of the power supply occur, the oven recovers the cooking in progress (if any) and continues it with the same parameters as before the power failure.

6.3.Errors and alarms

Errors and alarms can occur during the preparation and execution of cooking or washing processes. If this is the case, the central display will show the error or alarm code.



Figure 19. Error indicator

The table below shows the various errors and alarms, as well as possible solutions to them:

Error	Internal definition	Clarification
0	NO ERROR	No error.
1	ERROR GENERAL PURPOSE INPUT	Reserved. Not used.
2	ERROR OVERTEMPERATURE	Reserved. Not used.
3	ERROR OVERTEMPERATURE PCB	Overtemperature PCB. Check that the electronics' cooling fans are working properly, that there is enough space between the rear part and the wall, and that the ambient temperature is not excessive.
4	ERROR COMMUNICATION	Inter-board communication not responding. Check the cable between the power board and the control board.
5	ERROR EEPROM	Processor communication and EEPROM not working. Check the control board.
6	ERROR MOTOR	Engine error. Check the motor wiring. Overtemperature in the engine. Engine nailed down.
7	ALARM WATER	Reserved. Not used.
8	ERROR WASHING	Reserved. Not used.
9	ERROR PROBE1 TEMP SENSOR NOT CONNECTED	Reserved. Not used.
10	ERROR PROBE1 TEMP SENSOR SHORTED	Reserved. Not used.
11	ERROR PROBE2 TEMP SENSOR NOT CONNECTED	Reserved. Not used.
12	ERROR PROBE2 TEMP SENSOR SHORTED	Reserved. Not used.
13	ERROR PROBE3 TEMP SENSOR NOT CONNECTED	Reserved. Not used.

14	ERROR PROBE3 TEMP SENSOR SHORTED	Reserved. Not used.
15	ERROR PROBE4 TEMP SENSOR NOT CONNECTED	Reserved. Not used.
16	ERROR PROBE4 TEMP SENSOR SHORTED	Reserved. Not used.
17	ERROR PROBE5 TEMP SENSOR NOT CONNECTED	Reserved. Not used.
18	ERROR PROBE5 TEMP SENSOR SHORTED	Reserved. Not used.
19	ERROR PROBE6 TEMP SENSOR NOT CONNECTED	Reserved. Not used.
20	ERROR PROBE6 TEMP SENSOR SHORTED	Reserved. Not used.
21	ERROR PROBE7 TEMP SENSOR NOT CONNECTED	Reserved. Not used.
22	ERROR PROBE7 TEMP SENSOR SHORTED	Reserved. Not used.
23	ERROR PROBE8 TEMP SENSOR NOT CONNECTED	Probe camera not connected. Check the probe and wiring.
24	ERROR PROBE8 TEMP SENSOR SHORTED	Probe camera short circuited. Check the probe and wiring.
25	ERROR PROGRAM NOT TERMINATED	Reserved. Not used.
26	ERROR CLEANING PROGRAM NOT TERMINATED	Reserved. Not used.
27	ERROR CLEANING TEMPERATURE TOO HOT	Reserved. Not used.
28	ALARM RECOVERY TEMP TOO LOW	Reserved. Not used.
29	ERROR INVERTER	Reserved. Not used.

Table 8. Errors, alarms, and possible solutions

7. REMOTE CONTROL USE

7.1. Remote control setup

7.1.1. Creating a new user

The first step to configure the remote control is to create a user, with which the different ovens to be controlled will be linked later.

Create a user through the following link or QR code:

<https://mychef-432df.firebaseio.com/>¹




mychef.

Mychef control panel authentication



Figure 20. Authentication panel



E-mail
info@distform.com

Password
.....

Repeat password
.....

Create account

By clicking "Create account" you agree to our [Terms of service](#) and [Privacy policy](#).

Cancel

Figure 21. New user creation form

Once in the authentication panel, select "Create account" to create a new user account.

Note: the password must contain at least 6 characters.

To link a device (mobile phone, tablet, or computer) it is first necessary to set up a Wi-Fi connection in the oven. The following section (**7.1.2 Wi-Fi connectivity**) explains in detail how to set up this configuration.

¹ It is recommended to use the Google Chrome browser for better performance.



This web address has the functionality to send notifications when the cooking of the different linked ovens is finished, so that, if you want to enjoy this service, you have to give permission for the sending of pop-ups from this address.

7.1.2. Wi-Fi connectivity²

Once the oven is connected to the power outlet, it can be viewed as a Wi-Fi network from any device (mobile phone, tablet, or computer).

The Wi-Fi network will appear with the name "Mychef" followed by a number in parentheses (the MAC address of the device).




Figure 22. Access point of the oven from Windows

Then, this Wi-Fi network will be selected on the device with which we want to link the oven.

After selecting the Wi-Fi network, enter the code or password given by Mychef and wait for a configuration web portal³ to open automatically.

MAC:
Code:

In this configuration web portal, you will enter the data of your usual Wi-Fi network and the one you want to connect the oven to the internet (SSID).

² You can reset your Wi-Fi network settings at any time. See **section 7.3.1**.

³ If the configuration portal does not open automatically, open a web browser (Google Chrome is recommended) from a device connected to the Wi-Fi network and enter the following IP address in the browser: 192.168.4.1.

In the field "Mychef login email" you must enter the username that was created previously⁴ (**7.1.1 Creating a new user**).

It is important to write down the MAC address⁵ that appears in the different points of the configuration, since this is unique for each device and will be necessary to link the equipment to the remote control. We recommend copying the number after the title "MAC Address:" so you can paste it later.




Figure 23. The Wi-Fi network settings screen from different devices

Once all the fields have been completed, you should select the "Save" button to save the changes and start the connection.

⁴ If for any reason an invalid user is entered, it is possible to reset this configuration. See **section 7.3.1**.

⁵ If the MAC address of the equipment has not been noted, it can be displayed in the control panel of the oven once the Wi-Fi network has been set up. See **section 7.3.2**.



It is important that you connect to a Wi-Fi network with a 2.4GHz frequency band, as 5GHz networks are not compatible with Smart Control functionality.



Once the Wi-Fi network is configured, it is important to wait a few minutes until the Wi-Fi network disappears (Mychef + MAC address), if this does not happen it means that the configuration data entered to authenticate the Wi-Fi network is not correct, then the process must be started again.

7.1.3. Linking the oven to the device (mobile phone, tablet or computer)

Once an Internet connection⁶ has been established, the Wi-Fi network will no longer be visible. The next step will be to link our oven to the remote control. To do so, visit the following web address: <https://mychef-432df.firebaseio.com/> or code QR, log in with the user created in section 7.1.1 and linked to the oven in section 7.1.2.



If this is the first time you are linking a device, you will see the button combination shown in **Figure 24**.

To add a new device, select the "Add new device" button and fill in the form in **Figure 25** with a name for the device (which will serve to identify it) and the MAC address⁷ of the oven that we have previously copied.

Finally, we select the "Add device" button at the end of the form to add the remote control of the oven to our device (mobile phone, tablet or computer).

⁶ See **section 7.1.2** to configure the Internet connection.

⁷ The MAC address consists of six two-character blocks that can be either a number from 0 to 9 or a letter from A to F. If the MAC address of the equipment has not been noted, it can be displayed on the control panel of the oven. See **section 7.3.2**.




Figure 24. Session started without any linked device

Figure 25. Form for adding a new device

If all the previous steps have been carried out correctly, the control panel of the oven will appear with the different buttons and text boxes to display and change the different parameters that are configured in the linked equipment, as well as the actual values of temperature, humidity and cooking time.



It should be noted that when the user makes a change in this control system there is a delay between the database being updated and the change being sent to the equipment.

7.1.4. Control panel

In the **Figure 26** shows the control panel for the ovens linked to the user account. The functionality of each panel element is explained below.





Figure 26. Control panel detail

Block	Function	Description
A	Device selection box	In this selection box, a list of all devices linked to the user account will appear.
B	On/Off button	Equipment on/off button.
C	Start/Stop button	On/off and start/stop button for the oven.
D	Door status indicator	Indicates whether the door is open or closed.
E	Equipment status indicator	It indicates the different states of the equipment, see section 7.4.
F	Wi-Fi indicator	Indicates by a percentage the strength of the Wi-Fi signal.
G	Phase 1 button	Selecting this button redirects the front panel of the oven to phase 1 and displays the cooking parameters for this phase. This phase is always on.
H	Phase 2 button/indicator	Selecting this button redirects the front panel of the oven to phase 2, activates it if it is disabled, and displays the cooking parameters for this phase. If the button text appears as if it were disabled, it means that the phase is not active.
I	Phase 3 button/indicator	Selecting this button redirects the front panel of the oven to phase 3, activates it if it is disabled, and displays the cooking parameters for this phase. If the button text appears as if it were disabled, it means that the phase is not active.
J	Checkbox phase activation	Deselect if you want to deactivate a phase. Phase 1 is always active.
K	Input/indicator target cooking time of the oven (Set Point)	Allows you to enter the desired temperature value in the range [30,300] °C for manual cooking or indicates the target temperature value for a given recipe.
L	Input/target moisture indicator of the oven (Set Point)	Allows you to enter the desired humidity value in the range [-100,100]% for manual cooking or indicates the target humidity value for a given recipe..
M	Input/indicator target cooking time of the oven (Set Point)	Allows you to enter the desired cooking time value in the range [0-5940] minutes for manual cooking or indicates the target cooking time value for a given recipe.
N	Real oven temperature indicator (Real Point)	Indicates the real time temperature value of the oven's cooking chamber.
O	Real oven humidity indicator (Real Point)	Indicates the real time humidity value of the oven cooking chamber.
P	Real oven cooking time indicator (Real Point)	Indicates the value of the cooking time that has passed since the start of the cooking process.
Q	Fan speed button	Fan speed selection button, can be low speed (Slow) or high speed (Fast).

R	Recipe selection box	A list of all recipes entered by the user will appear in this selection box.
S	"Add Recipe" button	Button to add a new recipe to the user's recipe list. See section 7.5.
T	"Edit Recipe" button	Button for editing the cooking parameters of the recipe selected in the "recipe selection box" (N). See section 7.5.
U	"Send recipe" button	Sends the cooking parameters of the recipe selected in the "recipe selection box" (N) to the oven.
V	"Delete recipe" button	Removes the recipe selected in the "recipe selection box" (N).
W	"More information" button	It opens a window with information about the equipment: the use linked to the equipment, the minutes of operation of the oven and the temperatures of the electronics of the equipment.
X	"Add New Device" button	Allows you to link a new oven. See section 7.1.3.
Y	"Delete device" button	Allows you to remove a device from the list of linked computers.
Z	"Logout" button	Log out and redirect the page to the authentication panel.
AA	"Delete account" button	Once all the ovens are deleted, delete the user account.

Table 9. Control panel description

7.2. Google home setup and voice assistant⁸

7.2.1. Synchronizing oven to Google Home

The first step to be able to use the Google Home functionality and control our ovens using the Voice Assistant is to sign in with a Google account on our mobile device and download the Google Home and Google Assistant application.

⁸ Mychef's Intelligent Voice Control is currently only available in English, so you need to change the language of the mobile device you are using to English to enjoy the full functionality.




Figure 27. Google applications required

Once the two applications are installed, we start Google Home and follow the next steps:

1. On the app's Home screen, select Add "+" and then "Set up device".

+




Figure 28. Google Home application captures steps to be followed

2. Select the option "Work with Google" and then search the list of suppliers for the "Mychef Control" service.




Figure 29. Google Home application captures steps to be followed

3. Finally, the user will be redirected to the authentication server page to log in with the user and password created in **section 7.1.1**. It will wait for the authentication to be validated and then all the devices created in the control web application will be synchronized.



It is possible that in some cases the server is busy or that a message appears informing that the synchronization could not be carried out, the message should be omitted if the linked ovens appear on the start screen. If they do not appear, repeat all the steps in this section.



Whenever you add or remove an oven in the control web application, the Google Home startup screen will automatically update with the new devices, otherwise you need to unlink your account from the Mychef Control⁹ service and repeat the steps in this section to make the devices appear or disappear on the Google Home startup screen.

⁹ See **section 7.3.3**.




Figure 30. Authentication server screen and messages that appear while validating and synchronizing information




Figure 31. Google Home screen where all the ovens linked to the user's account will appear, along with all the smart devices that the user has associated with his Google account

7.2.2. Voice commands for oven control¹⁰

ON/OFF:	
- Turn on <i>Mychef</i> .	- Is <i>Mychef</i> on?
- Turn off <i>Mychef</i> .	- Is <i>Mychef</i> off?
- Turn on [all] ovens.	- Turn off [all] ovens.
START/STOP:	
- Start <i>Mychef</i> .	- Run <i>Mychef</i> .
- Stop <i>Mychef</i> .	- Start [all] ovens.
- Stop [all] ovens.	
TEMPERATURE CONTROL: (X = [30-300])	
- Set <i>Mychef</i> temperature to X .	- Set <i>Mychef</i> to X .
- What is <i>Mychef</i> temperature?	- What temperature is <i>Mychef</i> set to?
- Set [all] ovens temperature to X .	- What is ovens temperature?
HUMIDITY CONTROL: (X = [High, Medium, Low])	
- Set <i>Mychef</i> mode to Humidity X .	- Set <i>Mychef</i> to Humidity X mode.
- What mode is <i>Mychef</i> set?	- Is <i>Mychef</i> humidity X mode set?
- Set [all] ovens mode to Humidity X .	
TIME CONTROL: (X = [0-99 hours, 0-5940 minutes, 0-356400 seconds])	
- Run <i>Mychef</i> for X .	- Set <i>Mychef</i> timer to X .
- Start <i>Mychef</i> for X .	- How many minutes are left on <i>Mychef</i> ?
- Cancel <i>Mychef</i> timer.	- How many minutes are left on ovens?
- Increase <i>Mychef</i> timer X .	- Decrease <i>Mychef</i> timer X .
FAN CONTROL: (X = [High,Low])	
- Set <i>Mychef</i> fan speed to X .	- Set <i>Mychef</i> speed to X .
- What fan speed is <i>Mychef</i> set to?	- What is <i>Mychef</i> speed?
- Set ovens speed to X .	- What is ovens speed?

Table 10. Different voice commands compatible with the intelligent control

From the Google Home application's start screen, pressing the microphone icon, saying "OK Google" or "Hey Google", will open the Google Assistant which will listen to the voice

¹⁰ The word "Mychef" appears in these commands to refer to the oven in question, but this word can be replaced by the name you want to give the oven once it is added to the web control.

command the user says and if it is correctly understood as an oven control command, will perform the action requested or inform about the parameters asked.

You can also do this directly from the Google Assistant application or through any device that supports the Google Assistant such as a Google Home speaker.




Figure 32. Different voice commands understood and executed by the Assistant

7.2.3. Adding automated routines

It is also possible to add routines to Google Home, so that different actions are executed with a single voice command.

Below is an example where just by saying "Cook Pizza", Google Home will execute all the necessary commands to turn on the oven, set the desired temperature, humidity and cooking time and finally start a bake with these parameters.

1. Go to settings in Google Assistant and select the "Routines" icon.




Figure 33. Google Assistant application capture

2. Then manage routines and press the add icon (+).




Figure 34. Google Assistant Routines capture

3. In adding commands, the desired voice command will be written to execute the routine, in this example it will be "Cook Pizza".

4. Finally, under "Add action", all commands of **section 7.2.2** that you want the oven to perform in this routine are added. For this example, they will be as follows¹¹:
 - Turn Mychef on.
 - Set Mychef temperature to 260.
 - Set Mychef mode to Humidity Low.
 - Start Mychef for 17 minutes.
 - Start Mychef.




Figure 35. Routine configuration in the Google Assistant application

¹¹ The word "Mychef" appears in these commands to refer to the oven in question, but this word can be replaced by the name you want to give the oven once it is added to the web control.



Figure 36. Executing the configured routine by voice command in the Google Assistant application

7.3. Support functions

7.3.1. Reset Wi-Fi settings

It is possible to remove the Wi-Fi network settings as well as the user to which the oven is linked as follows:

- Turn off the oven by pressing and holding the START/STOP button.
- Once off, press and hold the fan icon on the front panel until you hear a "Click".
- See if the device's Wi-Fi Access Point appears, if not, repeat these actions again.

7.3.2. Show MAC address

You can view the MAC address of your device once you have set up a Wi-Fi connection to your computer as follows:

- Turn off the oven by pressing and holding the START/STOP button.
- Once off, press and hold the temperature icon on the front panel until you hear a "Click".
- The central display will show the digits of the MAC address in pairs in an orderly fashion.

If the Wi-Fi connection to your computer has not yet been set up, the MAC address can be seen in the name of the Wi-Fi access point.¹²

7.3.3. Unlink the "Mychef Control" service

To unlink the Google account to the "Mychef Control" service, follow the steps in **section 7.2.1** until the list of service providers appears, this screen will show that we are linked to the "Mychef Control" service with the number of devices synchronized. If you want to unlink the account, just select the linked account and choose "unlink".




Figure 37. Last window concerning the steps to be followed to unlink the account from the service

7.3.4. Desktop application for intelligent control

If the web control application is accessed through the "Google Chrome" browser, it is possible to download the page as an application, either on a mobile device or on a computer.

- **Computer:** Go to the menu at the top right of Chrome ; select "More tools" and "Create shortcut...". In the pop-up window that will open, put the desired name for the application and select the box "Open as window" and "Create". This creates a shortcut to our intelligent control that can be found in the home menu.




Figure 38. Pop-up window for creating the shortcut

¹² See **section 7.1.2.**

- **Mobile device:** Similarly, on the mobile device, go to the menu at the top right of Chrome ☰, select the option "Add to Home Screen" and add. This creates a shortcut to our intelligent control that can be found on the home screen of the mobile device¹³.




Figure 39. Pop-up window for adding the application to the home screen and application icon on a mobile device

7.4. Table of states

Status	Description
Online	The equipment is connected while waiting to start cooking or washing.
Offline	The computer is not connected or ready to receive and send data.
Cooking	The equipment is connected and performing a cooking.
Preheating	The equipment is connected and performing a preheating.
Adjust	The equipment is connected and has reached the heating temperature.
Washing	The equipment is connected and performing a wash.
Error	The device shows an error on the central display.
Connecting...	It is trying to connect with the oven.


Table 11. Different states that can be displayed on the control panel

7.5. Recipes

The remote control gives the possibility to enter an infinite number of recipes, and these will be compatible and visible to all the ovens that can cook them. To add a recipe, just fill in the different fields of the form that opens. The data to be entered are the name of the recipe, desired temperature and humidity, cooking time and fan speed.

¹³ In order to add the shortcut to the home screen, the Chrome application must have permissions to do this.

In the same way, if you want to edit a recipe, the same form will be opened with the data entered previously at the time it was created and it will be enough to change the data by the new parameters desired.



The image shows a recipe creation form with the following elements:

- Recipe name:** A text input field containing "Recipe 1".
- Phase selection:** Three buttons labeled "P1", "P2", and "P3". "P1" is currently selected and highlighted in grey.
- Enable phase:** A checked checkbox.
- Temperature:** A numeric input field with "260" and a "°C" unit.
- Humidity:** A numeric input field with "100" and a "%" unit.
- Time:** A numeric input field with "15" and a "Min" unit.
- Fan speed:** A toggle switch between "Slow" and "Fast". The "Fast" option is currently selected.
- Buttons:** A dark blue "Add recipe" button and a red "Cancel" button.

Figure 40. Recipe creation form

If a recipe is selected, the cooking parameter input fields are locked with the values of the recipe in question. To change the cooking values again, select Manual cooking.

8. MAINTENANCE

8.1. Cleaning

It is the responsibility of the owner to carry out regular maintenance and cleaning. To maintain the warranty, it must be possible to check that maintenance has been carried out correctly and according to the instructions detailed in this manual.

One of the important parts in the maintenance of the equipment is its cleaning. Therefore, the equipment should be cleaned more or less frequently depending on the area of the equipment.

Below is a table showing the frequency with which the different parts of the equipment should be cleaned.

PART OF THE EQUIPMENT	FREQUENCY
Inside the chamber	Daily
Compartment behind suction plate	Daily
Door gasket	Daily
Equipment outer plates	Daily
Door water drain	Weekly
Interior-exterior door compartment	Weekly

Table 12. Cleaning frequencies for Mychef ovens

Before starting any cleaning program, any trays, grids, grates, probes or other accessories inside the chamber must be removed.

8.1.1. Suction

The piece that separates the cooking chamber with the fan and the heating element can be removed to clean that area. In order to remove the guard, the guard screw (A) must be unscrewed, and the guard piece (B) must be lifted.




Figure 41. Suction plate fixing screws

Once the part has been removed, cleaning can be done either manually or automatically.



Extreme care must be taken when cleaning this part of the oven. Leave the door ajar and wait until the chamber fan stops.

When this process has been completed, the chamber fan suction part must be replaced in reverse.

8.1.2. Door gasket

Once the cleaning of the chamber has been completed, the washing process will continue with the seal that ensures the watertightness of the chamber. It is important that this part of the oven is clean and does not have any pieces of food embedded in it so that it can seal the chamber well and heat, water, or steam cannot escape when it is in operation.

To clean this rubber seal, a cloth soaked in water and a little bit of dishwasher is enough. Then the whole area is rinsed out and dried well.

The gasket should not be removed from its contour for cleaning, it should only be removed when it needs to be replaced.

8.1.3. Outer housing

To clean the outer casing, use a cloth moistened with water and dishwashing soap or specific stainless-steel cleaner. Then rinse and dry.

To clean the glass on the outside through the outer door, use glass cleaner and hand paper to avoid scratching the glass.

8.1.4. Control panel

To clean the control panel, use a cloth dampened with water and dishwashing soap. Then rinse and dry.

Never use agents with alcohols or solvents, as they may attack the metals or plastics in the control panel.

8.1.5. Front water drain

This piece is the one that allows water drops that may fall from the condensation of steam from the interior door to go to the drain, so it is important to keep this water collector clean and unobstructed.

Remove any bits of food that may have fallen out before cleaning. Then clean with a cloth wet with soap and water and finally rinse with plenty of water.

8.1.6. Interior/exterior door compartment

To clean this compartment, the outer door must be opened and the inner door clips opened so that the door can be opened and the chamber between the outer and inner door can be accessed.




Figure 42. Inner glass clamp

It is advisable to clean the inside of the outer glass and the inside glass on the outside with glass cleaning fluid and hand paper. For the inside of the inner glass, if the dirt is not excessive, you can proceed in the same way as the other glass. If there is a lot of dirt, an automatic cleaning cycle can be done to remove this excess dirt.

Once cleaning is complete, the inner door can be closed and secured with the staples.



Cleaning the oven with a pressure washer is harmful to the equipment and could result in breakage and void the warranty of the equipment.



Do not use the hand shower accessory on the door glass while it is hot, there is a danger of breakage due to thermal shock.

For the stainless-steel housing use a cloth dampened in a mixture of water and detergent, or specific detergent for stainless steel.



Never use cold water to wash the interior of the cooking chamber when it is above 70°C. Thermal contrast is harmful to the equipment and would void the warranty of the equipment.

8.2. Preventive maintenance

Mychef ovens are designed for intensive and long-lasting operation. For this to happen, in addition to regular cleaning tasks, preventive maintenance must be carried out. This preventive maintenance is specifically designed to prolong the life of your Mychef oven, minimize energy and water usage, and ensure excellent cooking quality without interruption.

This maintenance program is segmented into four types of revisions, A, B, C and D, which should be performed approximately every year or 2.000 working hours, whichever comes first.



These periodic reviews should be carried out every 2.000h of work or every year, whichever comes first.



These periodic checks must be carried out by an authorized service technician.

The following table shows the operations to be performed on Mychef ovens at each of the revisions. The table is circular, and from 20.000h of use or 10 years would start counting again on the left of the table. That is to say, at 22.000h it would correspond to revision A of 2.000h.

Mychef maintenance program		2000	4000	6000	8000	10000	12000	14000	16000	18000	20000
Review A	Firmware upgrade	X	X	X	X	X	X	X	X	X	X
	Water hardness test	X	X	X	X	X	X	X	X	X	X
	Cleaning of cooling fans	X	X	X	X	X	X	X	X	X	X
	Electronic cleaning	X	X	X	X	X	X	X	X	X	X
	Cleaning drainage tray and siphon	X	X	X	X	X	X	X	X	X	X
	Changing the gasket and adjusting the door	X	X	X	X	X	X	X	X	X	X
Review B	Pathogen-inactivated replacement (depending on model)		X		X		X		X		X
	Calibration of temperatures		X		X		X		X		X
	Adjustment of internal screws		X		X		X		X		X
Review C	Change of chimney and drain pipes					X					X
	Change of electrovalve for steam generation					X					X
	Change of resistance contactor (only models without TSC)					X					X
Review D	Change of motor										X
	Change of resistance and gasket										X
	Cambio of internal gaskets										X

Table 13. Periodic maintenance table



Regular maintenance ensures that your oven always works as designed.



Periodic maintenance must be accredited for warranty validity purposes.



Before any handling for maintenance or repair, the equipment must be disconnected from the power supply.



If the power cable is damaged, it must be replaced by your service department or similarly qualified personnel in order to avoid risks.